



Figures and illustrations in this Operation Manual are provided for reference only and may differ from actual product appearance. Product design and specifications may be changed without notice.

Help

The Help feature offers a lot of information about your TV operation. To use the Help feature, press the Home button, and then use the arrow and OK buttons to access to the Help menu. You can find how to troubleshoot from the list or keyword search. If you update APK, the Help feature and information will be updated.

Package

1.	LED TV.	1
2.	Remote control.	1
3.	Stands (Group).	2
4.	User Manual.	1
5.	Screw (Group).	1
6.	Remote control battery.	2
7.	Individual packing container, set.	1

Dear customer, before operating, please read all these safety and operating instructions completely and then retain this manual for future reference. Always comply with the following precautions to avoid dangerous situations and ensure peak performance of your product.

	CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN	
WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER TO QUALIFIED SERVICE PERSONNEL.		
	The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the products enclosure that may be of sufficient magnitude to constitute a risk of electric shock.	
	The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.	

Regulatory information

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- a. Relocate the receiving antenna.
- b. Increase the separation between the equipment and receiver.
- c. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- d. Consult the dealer or experienced radio/TV technician for help.

CAUTION

- × **Do not attempt to modify this product in any way without written authorization from supplier. Unauthorized modification could void the user's authority to operate this product.**
- × **Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance. Product design and specifications may be changed without notice.**

IMPORTANT WARNINGS AND CAUTION

Electrical energy can perform many useful functions, but it can also cause personal injuries and property damage if improperly handled. This product has been engineered and manufactured with the highest priority on safety. BUT IMPROPER USE CAN RESULT IN POTENTIAL ELECTRICAL SHOCK OR FIRE HAZARD. In order to prevent potential danger, please observe the following instructions when installing, operating and cleaning the product.

1. Attachments—Only use attachments/accessories specified by the manufacturer. Do not use attachments not recommended by the manufacturer. Use of improper attachments can result in accidents.

2. Water— To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.

3. Fire or explosion—Do not use or store flammable or combustible materials near the unit. Doing so may result in fire or explosion. Do not place any naked flame sources, such as lit candles, cigarettes or incense sticks on top of the TV set.

Warning: To prevent the spread of fire, keep candles or other open flames away from this product at all times.

4. Ventilation—When you install your TV, maintain a distance of at least 4 inches between the TV and other objects (walls, cabinet sides, etc.) to ensure proper ventilation. Failing to maintain proper ventilation may result in a fire or a problem with the product caused by an increase in its internal temperature.

5. ☐ This equipment is a Class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.

6. Power source—This product is intended to be supplied by a listed power supply indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company.

7. Overloading—Do not overload wall outlets, extension cables, or convenience receptacles on other equipment as this can result in a risk of fire or electric shock.

8. Voltage—Before installing this TV set, make sure your outlet voltage corresponds to the voltage stated on the appliance rating label.

9. Power plug — Do not defeat the safety purpose of the polarized or grounding-type plug. Most appliances recommend they be placed upon a dedicated circuit; that is, a single outlet circuit which powers only that appliance and has no additional outlets or branch circuits.

10. The MAINS plug of the apparatus is used as the disconnect device, the disconnect device shall remain readily operable. Keep you AC power socket close to you TV for easy plugging and unplugging.

11. Wall mounting—When mounting the product on a wall, be sure to install the product according to the method recommended by the manufacturer. This is a safety feature.

12. Stand— Do not place the product on an unstable trolley, stand, tripod or table. Placing the product on an unstable base can cause the product to fall, resulting in serious personal injuries as well as damage to the product. Always place the TV on furniture that can safely support the TV. Make sure the ends of the TV do not overhang the edge of the supporting furniture.

13. Entering of objects and liquids—Never insert an object into the product through vents or openings. High voltage flows in the product, and inserting an object can cause electric shock and/or short internal parts. For the same reason, do not spill water or liquid on the product.

14. Damage requiring service— This unit should only be serviced by an authorized and properly trained technician. Opening the cover or other attempts by the user to service this unit may result in serious injury or death from electrical shock, and may increase the risk of fire.

15. Replacement parts—In case the product needs replacement parts, make sure that the service person uses replacement parts specified by the manufacturer, or those with the same characteristics and performance as the original parts. Use of unauthorized parts can result in fire, electric shock and/or other danger.

16. Safety checks—Upon completion of service or repair work, request the service technician to perform safety checks to ensure that the product is in proper operating condition.

17. Children —Do not allow young children to play with the plastic bag that came with the television when you unpacked it. Failure to do so can result in suffocation, causing injury.

18. Batteries—The batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like. Do not dispose of any batteries in with the domestic waste. Return them to a collection point for old batteries.

19. Antenna —Install the antenna away from high-voltage power lines and communication cables and make sure it is installed securely. If the antenna touches a power line, contact with the antenna could result in fire, electric shock or serious injury.

20. Panel protection— The panel used in this product is made of glass. Therefore, it can break when the product is dropped or impacted upon by other objects. Be careful not to be injured by broken glass pieces in case the panel breaks.

21. It is recommended not to use the product in places where there is oil smoke or steam that may damage the material of this product.

22. Operating conditions: air temperature from 15 to 35 °C; humidity from 45 to 75%; atmospheric pressure from 86 to 106 to Pa (from 650 to 800 mm of mercury).





23. Transportation: Packed TVs are allowed to be transported by all modes of transport air temperature from +50 to - 40 °C and humidity from 75 to 100%.



24. ~ It Indicates alternating current.

== It Indicates direct current.

Safety Instructions

Important safety instructions

1. Read these instructions. 2. Keep these instructions. 3. Heed all warnings. 4. Follow all instructions. 	5. Do not use this apparatus near water. 
6. Clean only with a dry cloth. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. 	7. Do not block any ventilation openings. Ventilation should not be impeded by covering the ventilation openings with items such as newspapers, table-cloths, curtains etc. 

8. Do not install near any heat source such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. 	9. Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.	11. Educate children about the dangers of climbing on furniture to reach TV controls. 12. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over. Sudden stops, excessive force and uneven floor surfaces can cause the product to fall from the trolley.
13. For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the cable system. 	14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

NOTE

- × **Disposal of this product must be carried out in accordance to the regulations of your local authority. Do not dispose of this product with general household waste disposal.**
- × **Occasionally, a few non-active pixels may appear on the screen as a fixed point of blue, green or red. Please note that this does not affect the performance of your product.**
- × **Avoid touching the screen or holding your finger(s) against it for long periods of time. Doing so may produce some temporary distortion effect on the screen. It is not recommended to keep a certain still image displayed on the screen for a long time as well as displaying extremely bright images on screen, reduce the 'brightness' and 'contrast' when displaying still images.**
- × **The product is in standby mode under the network function, and it takes 30 minutes to enter the stable state.**

Google TV is the name of this device's software experience and a trademark of Google LLC.
Google, YouTube and YouTube Music are trademarks of Google LLC.

Getting started

Fitting the stand


Before you can install your TV set, you need to fit the stand. Alternatively, you can mount it on the wall. A Phillips screwdriver is needed to perform the installation.

Setting up the TV set

Place your TV set on a flat, stable surface (e.g. a table or a specially designed TV stand). Make sure that all cables are laid simply and safely and do not represent a trip hazard. The device must be connected to a mains socket using the mains cable. This mains socket must be easily accessible so that the mains plug can be removed immediately in the event of an emergency.

Fitting the batteries into the remote control

1. Turn the remote control over with its underside facing upwards, insert a finger into the recess, and push the battery compartment cover in the direction of the arrow. Remove the battery compartment cover.



2. Insert the batteries supplied into the remote control. Make sure that you insert the batteries correctly with the polarity as shown inside the battery compartment.
3. Replace the battery compartment cover and push in the opposite direction to the arrow until it clicks into place.



Caution: Remove the batteries from the remote control if you are not going to use the device for an extended period of time. Otherwise, the remote control can be damaged by leaking battery acid.


Controls and connections



Caution:

Before connecting or disconnecting any cables, switch off all related devices (also the TV). Otherwise you could damage the devices.

Back



- 1. OPTICAL OUTPUT:** Connect to an external digital audio device.
- 2. EARPPHONE:** Earphones/headphones jack.
- 3. CI:** Common Interface slot.(Not available for model 32WGC5520S)
- 4. USB2.0:** USB port. Connector a USB Storage device for multimedia file playback.
- 5. MINI AV-IN:** AV audio/video signal input.
- 6. HDMI:** HDMI (High-Definition Multimedia Interface) input. (HDMI1 supports eARC function).
- 7. TV1:** For connection of the external antenna.
- 8. TV2:** Connection for satellite antenna (TV2) (SATELLITE).
- 9. LAN:** Local area network (LAN) port. Connect a LAN cable to this port to connect to the Network.




The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Remote control

Definition of the buttons on remote control:


Nº	Buttons	Description
1.	Power (⏻)	Switch between working and standby status.
2.	Mute (🔇)	Turn on/off the sound.
3.	👤	Manage Google Account. (It is valid after login)
4.	Setup (⚙️)	Display the Dashboard interface.
5.	🗣️	Microphone / Google Assistant Use your voice to search for shows, control devices, and more - just ask Google Assistant.
6.	◀️, ▶️, ▲, ▼	Select items or adjust values.
7.	Direction/OK	1. Show the main menu.(In TV mode) 2. Confirm the operation.
8.	Back (⬅️)	Return to previous menu or exit the menu.
9.	📺	Electronic program guide.
10.	Home (🏠)	Display home page.
11.	CH +/–	Change channel.
12.	VOL +/–	Turn up/down the volume.
13.	Source (📡)	Display signal source menu.
14.	Menu (:≡)	Show OSD menu. (Non-smart mode.)
15.	NETFLIX	Open application.
16.	YouTube	Open application.
17.	prime video	Open application.
18.	YouTube Music	Open application.



Connecting antennae, Internet and external devices


Connecting a digital audio system

You can connect your TV set to a digital audio system (e.g. amplifier, home cinema). Connect the plug at the end of a coaxial audio cable (not supplied) to the Digital Audio Out connection on your TV set.



Connecting EARPHONE

You can connect EARPHONE or an analogue playback device to the socket marked with a headphones symbol. Use an audio cable with a 3.5 mm jack-type plug.



CI card slot

If you have purchased a subscription for watching scrambled programmes with a Pay TV provider, you can insert the module with the CI or CI+ card into this slot. For more information, please read the documentation supplied with your CI card.




Caution:

Switch your TV set off before inserting or removing the CI module. Otherwise you could damage the module or the TV set.

Inserting the CI card

Insert the module with the CI or CI+ card into the CI card slot. Make sure it is the right way around.




Removing the CI card

To remove the CI card, carefully pull it out of the CI card slot.

The CI/CI+ module is initialised after you switch the TV set on. This may take a little while. You should then be able to view the scrambled channels. If this is not the case, consult your Pay TV provider to check that the signal has been enabled for you.


Connecting USB device

The TV has USB 2.0 ports for connection with appropriate mass storage devices.




Connecting an external device with MINI AV-IN output

Connect external devices via the AV jack directly to TV by using a Mini AV cable. In order to play the audio and video signal fed in from the external device on the TV, select the signal source "AV".




Connecting external equipment with HDMI interface

HDMI is the abbreviation for "High Definition Multimedia" and allows the digital transmission of both audio video signals over the same cable. In order to play the audio and video signal fed in from the external device on the TV, select the signal source as appropriate.




Connecting the TV antenna or cable TV

You can connect the cable from your indoor or outdoor antenna or cable TV to the antenna socket.



Connecting the satellite antenna


You can connect the cable from your satellite antenna to the TV2 SATELLITE socket. To switch to satellite reception, select signal source "SATELLITE".



Connecting the network cable (LAN connection)



You can also establish an internet connection via WiFi.



Getting started

Powering on

Check that the TV is in standby mode. This means the mains cable must be connected to a working mains socket. Then press the  button on the remote to turn on the TV.

Powering off

To power the TV off, either press the Power button on the device or press the  button on the remote control.

After use Cleaning



Warning:

Make sure the device is unplugged from the mains power before cleaning. Otherwise, there is a risk of electrocution!

Never spill or spray any type of liquid into the unit. Only use a clean, dry cloth for cleaning the casing. Never use aggressive liquids. When very dirty, use a slightly dampened cloth. Clean the screen with a special cleaning cloth for screens.



Caution: when you clean the screen, hold the device steady with one hand and carefully clean the screen with the other. Otherwise, the device could tip over and get damaged or cause injuries.

Storage when not in use

If you do not plan to use the device for an extended period of time, unplug the power cord from the socket and remove the batteries from the remote control. Make sure that the storage temperature is between 15 °C and 45 °C and the relative humidity does not exceed 90%.

Transport

If you wish to move the device a short distance, proceed as follows to transport the device:

1. Disconnect the device from the mains.
2. Remove all cables connected to the device.
3. If you wish to move the device outside your building, demount the base and the optional side supports or the mounted wall bracket by reversing the procedure.
4. Pack the TV set up carefully. Take special care to ensure the corners of the casing and the screen are well protected.
5. Take the TV set and its accessories to its new location and recommission it.

Disposal of old electrical appliances



The European directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal unsorted municipal waste stream. Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain, and reduce the impact on human health and the environment. The crossed out "wheeled bin" symbol on the product reminds you of your obligation, that when you dispose of the appliance, it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliance.



This product meets the requirements of EU directives on electromagnetic compatibility and electrical safety.

Trouble-shooting

You can solve most common problems yourself using the solutions below. If the problem persists after checking the suggested solutions, please contact your reseller.

General problems

The TV set will not switch on.

- Plug the power cable of the TV set into a working mains socket.
- Replace the batteries in the remote control.
- Unplug the plug of the power cable from the mains socket, wait approx. 30 seconds and plug the power cable back in. The device should then work normally.

The remote control does not work

- Is there an obstruction between the remote control and the sensor on the TV?
- Replace the batteries.

- Make sure that the remote control sensor is not exposed to direct sunlight.

No picture

- Are all the connection cables to external signal sources properly connected?
- Is the connection cable to the external signal source damaged?
- Have you selected the correct signal source on the TV set?

TV reception problems

No picture

- Is the antenna plugged in properly? Is the antenna cable damaged?
- Is the antenna cable plug firmly connected?
- Have you selected the correct signal source on the TV set?
- Have you already executed a channel search at your present location?

Poor picture

- Is the antenna plugged in? Adjust the antenna.
- Check that the channel is tuned properly.
- Adjust the picture settings, such as brightness, colour, sharpness.

No sound

- Is the sound muted? Press the  button .
- Is the volume turned down? Press the + button .

No colour

- Adjust the colour setting.
- Check the programme is broadcast in colour.
- Check that the channel is tuned properly.

Multimedia playback problems

File is not played back

- Check that the USB mass storage device contains compatible files.

Problems with playback from external devices

No sound

- Check that the audio cable is properly connected or damaged.
- Make sure that you have selected the correct signal source on your TV set.

Sound is distorted or humming

- Clean the connector plugs.
- Replace the connection cable to the external device.

Problems with online services (Smart TV)

If you are using a cable network connection (LAN)

- Check that the network cable is properly connected.
- Check whether the network cable is damaged.
- Check whether you can access the internet from another device on the network .
- It is possible that the server for the selected service is temporarily down.
- Check the network settings on the TV set.

If you are using a wireless network

- Check whether you can access the internet from another device on the wireless network.
- It is possible that the server for the selected service is temporarily down.
- Check the network settings on the TV set.

Specifications

WI-FI	
Frequency range	Transm ission power (max)
2.412GHz-2.472GHz (2.4G wifi)	<20 dBm
5.180GHz-5.320GHz (5G wifi)	<20 dBm
5.500GHz-5.700GHz (5G wifi)	<20 dBm
5.745GHz-5.825GHz (5G wifi)	<14 dBm

Bluetooth	
Frequency range	Transmission power (max)
2.402GHz-2.480GHz	<10 dBm

The device complies with RF specifications when the device used at 20 cm from your body. The operation frequency in 5150-5350MHz of Wi-Fi 5G are restricted to indoor usage only.



Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

Specifications

Model		24WGC5500S
Screen Size		24" (60cm)
Resolution		1366 x 768
Brightness (cd/m)		150/180
Contrast ratio		2250:1
Aspect Ratio		16:9
Viewing angle		178 x 178
Power Input		~100-240V 50/60Hz
VESA		200 x 100
Dimensions, mm	Without stand	536 x 77 x 330
	With stand	536 x 156 x 360
Weight, kg	With stand	2.2
Energy efficiency class		E
Energy consumption in working mode, W		17
Annual consumption, kW * h.		17
Power consumption in standby mode, W		0.5

Specifications

Model		32WGC5500S/32WGC5520S
Screen Size		32 "(80cm)
Resolution		1366×768
Brightness (cd/m)		150
Contrast ratio		2250:1
Aspect Ratio		16:9
Viewing angle		178/178
Power Input		~220-240V 50/60Hz
VESA		100×100
Dimensions, mm	Without stand	728×75×426
	With stand	728×223×480
Weight, kg	With stand	3.4
Energy efficiency class		E
Energy consumption in working mode, W		26
Annual consumption, kW * h.		26
Power consumption in standby mode, W		0.5

Specifications

Model		40FGC5500S
Screen Size		40"(100cm)
Resolution		1920 x 1080
Brightness (cd/m)		220/260
Contrast ratio		5000:1
Aspect Ratio		16:9
Viewing angle		178 x 178
Power Input		~100-240V 50/60Hz
VESA		200 x 200
Dimensions, mm	Without stand	893 x 82 x 509
	With stand	893 x 198 x 561
Weight, kg	With stand	5.6
Energy efficiency class		F
Energy consumption in working mode, W		39
Annual consumption, kW * h.		39
Power consumption in standby mode, W		0.5

Note: The technical data and design may be changed without prior notice. All the pictures in this user manual are for illustrative purposes only and may be used for reference. Depending on the model, the actual product shall prevail.