



PLUG & PLAY WIRELESS CHARGER



Enjoy it.



Safety Notes

This whicle security system has been manufactured according to established safety guidelines. However, dangers may still occur if the safety notes in this manual is not observed. This manual is intended to familiarize the user with the wireless charger important functions. Read this carefully, prior to using the wireless charger. Keep this manual in an easily accessible location. In addition, do observe the instructions of the devices used in conjunction with this wireless charger.

Attentions

- Assign a mounting location that will not obstruct drive in any circumstances. Or cause injuries to drives and passengers in case of emergency brake or accidents.
- Ensure all wires are connected properly, and that the unit is functioning well before fitting the unit into the mount.
- Any unauthorized installation, disassembly or modification may cause malfunction to the unit and void warranty of the unit.
- Always use only the parts that are included with the units only.
- Do not damage vehicle components when drilling holes for the mount.
- Do not expose device to direct sunlight or store in high temperature environment.
- Do not drop or expose device to high vibration/impact.

- Vehicle may differ from the description provided here. Consult an authorized Blaupunkt dealer or vehicle's manufacturer if the information provided here does not fit your specific installation requirement.
- The device is intended for installation and operation in 12V vehicle system outage.

This manual may be updated from time to time without any notice.

Disclaimer

In no event shall Blaupunkt be liable for any direct, indirect, punitive, incidental, special consequential damages to property or life and whatsoever arising out of or connected with the use or misuse of our products. USA & CANADA: This product is not intended for sale in the United States and Canada. If purchased in the U.S. or Canada, this product is purchased on a s-is basis. No warranty, whether expressed or implied is provided in the U.S. or Canada.

SPECIFICATIONS

Input Voltage: 9V - 16V
 Output Current: 9V/1.1A
 Transmitting Power: 10W

Operating Frequency: 110kHz-205kHz
 Operating Temperature: -30°C ~ 80°C

· Protection: Overvoltage, over current, high temperature, reverse polarity & short circuit

Indicator Light Status

LED Indicator Light	Status	
White	Standby mode (no charging)	
Blue	Device is charging	
Flashing Blue and White	Foreign object is detected	

TROUBLESHOOTING

If any of the following problem occur, please resort to Troubleshooting for the possible solutions. Consult Blaupunkt authorized dealer if problem persist.

Problem	Problem	Solution
Indicator light	No ACC power supply.	Activate the ACC power supply.
does not work.	Device working abnormal.	Restart ACC and the device.
Blue or white	A foreign object is detected	Remove the foreign object from
indicator light is	between the phone and the	the device or clean the device with
flashing	device.	dry cloth.
Device is not	Wireless transmitter unidenti-	Please use the compatible
charging	fied or don't start.	smartphone.
	The phone is deviating the	Ensure smartphone is placed on the
	transmitter range.	center the device.
	•	•

OPERATION INSTRUCTION

1. Turn on


 Start car ACC, the LFD indicator will illuminate in white colour

2. Charging Smartphone

- · When smartphone is placed at the center of the device, the LED indicator switched to blue colour.
- · Charging status will reflect on the smartphone screen.

3. Charging Area

a) X-axis movable area: -15mm ~ 15mm



b) Y-axis movable area: -35mm ~ 35mm Wireless Charger c) Z-axis movable area: 0mm ~ 8mm



