

CHAINSAW CS3120



The CS3120 cordless chainsaw is an ideal tool for work in the garden or on the allotment. It is lightweight, handy and easy to use. It doesn't need a cable or fuel, just charge the 18V battery and you're ready to go. You can cut wood, branches or bushes with precision and speed.



DISTRIBUTOR:

2N-Everpol Sp. z o.o. - BLAUPUNKT COMPETENCE CENTER,
02-801 WARSZAWA, 403A PUŁAWSKA St., POLAND
Tel: +48 22 688 08 00, www.everpol.pl, info@everpol.pl

FEATURES AND SPECIFICATIONS:

- Voltage: 18 V
- Total chain guide length: 250 mm
- Chain speed: 5.7 m/s
- Speed: 3000 min⁻¹
- Maximum depth of cut: 235 mm
- SDS system – tool-free chain tension adjustment
- Automatic chain lubrication (Oil tank 0.2 l)
- Motor type: brushed DC
- Battery type: 18 V Li-Ion, 4.0 Ah or 5 Ah recommended (not included)

DIMENSIONS AND WEIGHT OF THE DEVICE:

- Dimensions: 64 x 22 x 20 cm
- Weight: 3.06 kg

LOGISTICAL DATA:

Unit packaging

- Dimensions: 45.5 x 22.5 x 23 cm
- Weight: 3.66 kg.

INCLUDES:

- Chainsaw
- Chain
- Chain guide
- User Manual
- Warranty card

EAN code: 5901750507519

CN code: 8467 22 10

