## BLAUPUNKT



# **POWER SPEAKERS**

## **BGx 2xxx SERIES**



Enjoy it.

### INTRODUCTION

Proper system planning is vital in order to maximize the device's performance and road safety. Plan your installation carefully to avoid compromising performance reliability of the system. Consult an authorized Blaupunkt delaler for installation or reparation. Read the manual carefully before operating the device for the first time.

#### Safety Notes

Ensure to follow below safety notes during installation and wiring connection: -

- Disconnect the negative terminal of the battery. Refer to the safety notes of the vehicle manufacturer.
- Ensure positions of the holes are nowhere near the vehicle component to avoid any damage during drilling.
- Ensure cross section of the cable is no less than 2.5mm<sup>2</sup> if the positive and negative cables are too long.
- Incorrect installation may result in malfunction of the device or the car sound system.

#### Installation and Connection Instructions

- Select a dry and well-ventilated location to install the device.
- The device must not be installed in overly exposed location such on the rear shelf, rear seat etc.
- The installation location must be suitable for screw holes and have stable ground support.

#### Voltage Supply

- Use the supplied power extension cable to connect to the positive battery terminal.
- Firmly and carefully connect the ground lead to a bare metal point on the vehicle chassis.
- The control of the device should be a

two-channel control, either via the preamplifier output of the car sound system. A control solely via the right or left channel is also possible since the low-frequency portion of the music is generally identical on both channels.

#### Disclaimer

In no event shall Blaupunkt be liable for any direct, indirect, punitive, incidental, special consequential damages to property or life and whatsoever arising out of or connected with the use or misuse of our products.

USA & CANADA: This product is not intended for sale in the United States and Canada. If purchased in the U.S. or Canada, this product is purchased on as-is basis. No warranty, whether expressed or implied is provided in the U.S. or Canada.

#### **Recycling and Disposal**



Do not dispose your old unit in the household trash! Use the return and collection items available to dispose of the old device

This manual may be updated from time to time without any notice.

#### **BGx 2402 N**

Pair of 4.0" 2-way coaxial speakers with injected cone including mounting hardware

Max. Power Handling: 70WNormal Output Power (RMS): 20W

Impedence : 4ohms


• Frequency Response: 100-20,000Hz


Frequency Response
 Sensitivity: 86dB

· Mounting Depth: 46mm

• Mounting Hole Diameter: 95mm

· Surround: Rubber Edge





#### **BGx 2652 N**

Pair of 6.5" 2-way coaxial speakers with injected cone including mounting hardware

Max. Power Handling: 105W

• Normal Output Power (RMS): 35W

· Impedence: 4ohms


• Frequency Response: 70-20,000Hz


Frequency Respo
 Sensitivity: 88dB

· Mounting Depth: 59mm

· Mounting Hole Diameter: 141mm

· Surround: Rubber Edge





#### **BGx 2693 N**

Pair of 6.0" x 9.0" 3-way triaxial speakers with injected cone including mounting hardware


Max. Power Handling: 135W
Normal Output Power (RMS): 45W


Impedence : 4ohms

• Frequency Response: 55-20,000Hz

Frequency ResponSensitivity: 88dB

Mounting Hole Diameter: 82mm
Diameter Hole: 222x149mm
Surround: Rubber Edge





#### BGx 2652 C

Pair of 6.5" 2-way component speakers with injected cone including mounting hardware

· Max. Power Handling: 130W

· Normal Output Power (RMS): 40W

Impedence: 4ohms


• Frequency Response: 70-20,000Hz


Sensitivity: 88dB

· Mounting Depth: 59mm


· Mounting Hole Diameter: 141mm

Surround : Rubber Edge





### INSTALLATION



## **TROUBLESHOOTING**

If any of the following problem occur, please resort to Troubleshooting for the possible solutions. Consult Blaupunkt authorized dealer if problem persist.

Problems	Possible Causes	Solutions
Speaker does not work	Incorrect or loose wiring connection.	Ensure proper wiring connections of speaker.
	Fraying or broken cables.	Repair or replace if the cables are damaged.
	Speaker is damaged.	Replace with a new speaker.
Distorted and hissing sound	Voice coil or speaker cone is damaged.	Replace with a new speaker.



BGx 2402 N 1 111 20 030 07 01

**BGx 2652 N** 1 111 20 031 07 01

**BGx 2693 N** 1 111 20 032 07 01

BGx 2652 C